

LUMI DRIVE FU2000


Frequency Inverter 3.0kW

Operation Manual

Operation Manual

Static Frequency

Inverter



230V - Version

- | | | |
|-------------------------|----------|---------------|
| FU2233 / 2233-RT | – | 0,75kW |
| FU2237 / 2237-RT | – | 1,5kW |
| FU2239 / 2239-RT | – | 2,2kW |

400V - Version

- | | | |
|-------------------------|----------|------------------|
| FU2404 / 2404-RT | – | 1,5kW |
| FU2408 / 2408-RT | – | 2,2/3,0kW |

Software-Version 7.2D
Applicable from Series No: 00 269
Issued: October 1991

HOW TO USE THIS MANUAL



CAUTION:
Prior to Installation and initial Start-up of the Equipment this Manual should be thoroughly studied by Personnel authorized and qualified to work on Electrical Drive Systems. False Handling of the Equipment could be Hazardous to Personnel and/or Equipment.

CAUTION:
Electronic Components are not 100% Fail-Safe. It is the User's Responsibility to return the Drive System to „SAFE“ Mode in Case of Failure of an individual Component. For Passenger Transport Systems it is essential to provide external Safety Precautions operating independently from the System's Circuitry.

This Operation Manual is valid for Frequency Inverters Series FU2000.

The front cover can be folded out to illustrate the Frequency Inverter's construction and the location of individual components or modules. This fold-out is provided as a guide line through the entire manual.

Following a tabulation-type listing of abbreviations used in this manual, chapter 1 contains general information related to Frequency Inverters Series FU2000.

Chapters 2 and 3 include essential information concerning technical data as well as instructions related to storage and transportation of the equipment.

Chapters 4 and 5 contain instructions for mechanical as well as for electrical installation. Wiring connections are shown in chapter 6.

Detailed instructions in regard to parameter entries via Digital Control Unit are given in chapter 7.

Information generally applicable to the operation of Frequency Inverters is given in chapter 8.

Finally, chapter 9 describes, in detail, initial assembly and installation, as well as a listing for trouble shooting and repairs.

The manual contains complete information required for normal installation and operation of the equipment; however, should questions arise beyond the scope of this manual, you are kindly requested to contact

LUST electronic
systeme

LUST Electronic-Systeme GmbH
Gewerbestraße 5-9
D-6335 Lahnau 1

Phone 0 64 41 / 6 02-0
Telefax 0 64 41 / 6 02-37



Please study this Manual prior to Installation and Start-up.

INDEX


-ay-out Diagram (Front Fold-out)			
How to use this Manual			
General Information			
About Frequency Inverters in General	2	6.2	Diagram of Wiring Terminals
Special Characteristics	2	6.2.1	Control Terminals (X2)
Application Range	3	6.3	Specification of Control Terminals (X2)
Model Codes	3	6.4	Control Functions
		6.4.1	Analogous Entry of Nominal Frequency Value
		6.4.2	Digital Entry of Nominal Frequency Value
		6.4.3	Table of Control Functions
			'RH Start', 'LH Start', 'Reversal', and 'Ramp-Controlled Brake Application'
		6.4.4	Line Connection via 'STL'/STR'
		6.4.5	Reset
		6.4.6	Control Functions via Digital Inputs S1IND and S2IND
Technical Data			
Power Output	4	6.4.7	Table of Control Function 'Frequency Reversal'
Power Supply Input	4	6.4.8	Table of Control Functions 'U/F Curve Reversal' and 'Ramp Reversal'
Dimensional Data	4	6.5	Programmable Output of Digital Signals (S1OUT - S3OUT)
Ambient Conditions	5	6.5.1	Signal Output 1
		6.5.2	Signal Output 2 and 3
		6.6	Programmable Analogous Output (SOUTA)
		6.7	Frequency Output (FOUTF)
		6.8	Serial Interface RS485
		6.8.1	Attributes of the Bus-System
Transportation, Storage and Mechanical Handling			
Instructions for Mechanical Installation	7		
Over-all Dimensions, Bore Patterns	7	7	Entry of Parameters via Digital Control Unit
Type of Housing Protection	7	7.1	Functional Description
Mounting Instructions	7	7.1.1	LCD Display
Minimum Spacing	8	7.1.2	Function of LEDs
Mounting of Venting Attachment LA2000	8	7.1.3	Control Components for Entry of Parameters
		7.2	Structure of Menu
Instructions for Electrical Installation			
Rules and Regulations	9	7.2.1	Password
Protective Measures	9	7.2.2	Parameter Settings
Control Devices	10	7.3	Control Level 1 / Menu for Start-up
Cable Routing	10	7.3.1	Entry of Operational Mode
Listing of Fuses	10	7.3.2	Frequencies
		7.3.3	Ramps
		7.3.4	U/f Curves
		7.3.5	Start Options
		7.4	Control Level 2 / Entry of Parameters
Electrical Connections	11	7.4.1	Parameter for Input of Nominal Value
Power Terminals (X1))	11	7.4.2	Parameter for Actual Value Display
Power Supply Terminals FU2230	11	7.4.3	Operating Time
Power Supply Terminals FU2400	11	7.4.4	Parameter for U/f Curve Sets and Ramp Reversal
Motor Connection FU2230	12	7.4.5	Parameter for DC-Stop Torque
Motor Connection FU2400	12	7.4.6	Overload Protection
Brake Chopper Connection	13	7.4.7	Allocation of Special Outputs
Retrofitting an internal braking resistor	13	7.4.8	Program Number
Retrofitting an external braking resistor	14	7.4.9	Modulation Frequency
		7.4.10	Device Data

INDEX

7.5	FU2000-RT Frequency Inverter	36
7.5.1	Real Time Signal processing	36
7.5.2	Parametric Filter Time constants	36
7.5.3	Self-optimising dynamic chopping protection	37
7.5.4	Automatic Moment increase during acceleration	37
7.5.5	Automatic Voltage increase for sliding ring motors	38
7.5.6	Modulation Frequency	38
7.5.7	Characteristics changeover	38
7.5.8	FU2000-RT Parameter List	39
7.5.9	Circuit Example for optimum time positioning using FU2000-RT	40
8	General Info for the Operation of Frequency Inverters	41
8.1	Remarks Concerning RPM Control of AC Motors via Frequency Inverter	41
8.2	Standard Graphs for Motor Loads	41
8.3	Block Diagram	42
8.4	Electrical Dimensioning of Motor Drives	43
9	Initial Start-Up	44
9.1	Initial Installation	44
9.2	Repairs	45
9.3	Evaluation of LED Displays	46
10	Structure of Menu / Listing of Parameters	47
10.1	Control Level 1	47
10.2	Listing of Parameters	48
11	Addresses	49
11.1	Representatives in Germany	49
11.2	Representatives in other countries	50

1

ABOUT FREQUENCY INVERTERS IN GENERAL




Frequency Inverters Series FU2000 are designed for energy-saving, stepless speed variation control of AC motors in the range of 0,75kW through 3,0kW. High-performance Micro-processor technology, as well as SMD assembly techniques, were utilized to provide a compact, easy-to-operate piece of equipment. Application possibilities for electronically controlled speed variation of rugged AC motors have thus been expanded considerably. Frequency Inverters produce AC networks of variable current frequencies.

Simultaneous variation of phase voltage in accordance to a chosen U/f curve serves to operate the motor at constant magnetic flow up to nominal frequency. This results in constant torque during acceleration up to the desired nominal speed level. Also, the inverter's performance remains constant.

Existing asynchronous AC motors can be retro-fitted for operation via Frequency Inverter. In addition to advantages realized from controlled speed variation other benefits can be obtained, such as minimized maintenance requirements, reduced wear and tear due to controlled acceleration and deceleration, and reduced work cycle times due to higher average speed ranges. The adaptation of linear speed of a conveyor belt, for example, in correlation to a primary work process is easily realized through frequency conversion. Furthermore, the operation of pumps and venting equipment via Frequency Inverter results in considerable energy savings.

- Compact design, permitted through utilisation of SMD assembly techniques,
 - Entirely digital structure with 16-bit Microprocessor,
 - High device efficiency,
 - Smooth rotation, even at lowest speed levels,
 - Control Inputs and Outputs are free of potentials and compatible with SPS (Storage Programmable Control) circuitries,
 - High overload properties with monitoring of the current/time factor ($I \times t$),
 - High switching frequency, thus reduction of motor noise,
 - Extensive software options for numerous applications,
 - Serial interface RS485 for integration with primary control systems,
 - Simplified initial start-up and control through integration of a digitally structured operation control unit with LCD display and coded messages,
 - Non-volatile occurrence memory for quick detection of malfunctions (failures), minimizing down times.
 - LUWORK compatible PC software for parametrizing, controlling, monitoring and documenting.
 - Drivecom compatible Connection to real time Drivecom bus system.

APPLICATION RANGE**Conveyance, Moving,
Positioning**

If constant, jerk-free progression of motion is critical, or if work cycle times are to be reduced with simultaneous reduction of wear and tear.

**Dosage, Climate Control,
Regulation**

Reduction of energy consumption as well as of wear and tear on pumps and airconditioning equipment; if precise dosage and dosage regulation with high-degree process integration are required.


**Machining and
Manufacturing**

For optimized constant machining speed and work cycle time reduction, and for improvement of machined surface quality.

MODEL CODES

FU 2 40 4

FU 2 23 9



Continuous Current of Device

Power Supply Voltage
230V AC (400V AC)

Series

Frequency Inverter

TECHNICAL DATA

2.1

POWER OUTPUT

	Code	Dim.	FU2233	FU2237	FU2239 (LA2000)	FU2404	FU2408 without LA2000	FU2408 with LA2000
Motor Rating / 4-Pole Std. Motor	P	kW	0,75	1,5	2,2	1,5	2,2	3,0
Constant Capacity	S	KVA	1,6	2,7	4,2	2,7	3,8	5,5
Current, continuous	I	A	3,5	6,2	9,6	3,5	5,0	7,2
Continuous load	-	%			110			
Overload for 60 seconds	-	%		50	30	50	10 at present (30 from May91)	
Voltage	U	V		3 x 0 ... 230			3 x 0 ... 400	
Rotary Field Frequency	f	Hz			0...400			
Frequency Solution	f	%			0,1 of FMAX, 0,05Hz min.			
Type of Load	-	-			resistive / inductive			
Max. permiss. overload current for 60sec	I _{MAX}	A	5,3	9,3	12,5	5,3	8,0 (9,3)	8,0 (9,3)

2.2

LINE POWER SUPPLY INPUT

Voltage	U	V	230 -30/+15%	3 x 400 -20/+15%
Line Power Frequency	f	Hz	50/60 ±10%	
Perform. Factor of Fundament. Oscillation	-	cosφ	> 0,97 (only effective power)	
Input Wire Gauge	A	mm ²	multistrand 1,5 / single strand 2,5	
External Line Fuses (delay-type)	I	A	16	
Permissible Line Voltage Asymmetry	ΔU	%	3	

2.3

DIMENSIONAL DATA

Physical Dimensions	WxH xD	mm	216 x 256 x 128	216 x 256 x 162 with LA2000 (216 x 340 x 162)	216 x 340 x 162
Weight	-	kg	appr. 4	appr. 5,5	appr. 6
Protection Rating	-	-		IP10 / VBG4	
Mounting Orientation	-	-		Vertical on wall or panel	

	Code	Dim.	FU2233	FU2237	FU2239 (LA2000)	FU2404	FU2408 without LA2000	FU2408 with LA2000
Max. internal temperature of equipment up to 1000m elevation	T	°C			60			
Max. permissib. ambient Temperature, or Temp. of Coolant up to 1000 m elevation	T	°C		40	30 (40)		40	
Reduction of Output Power related to elevation	H	m			5% Reduction per 1000m (3000Ft.) above 1000m (3000Ft.)			
Reduction of Output Power related to ambient Temperature	—	%/°C			2% per °C above 40°C ambient temperature maximum ambient temperature: 55°C			
Power Loss	P	kW	0,10	0,15	0,23	0,13	0,20	0,25
Relative Humidity	—	%			90% non-dewing			
Vibration	—	—			mechanically 0,4g / electrically 2g			
Efficiency	η	%	94	95	95	95	95	96
Storage Temperature	T	°C			-10°C ... +60°C to VDE 0160			

TRANSPORTATION, STORAGE AND MECHANICAL HANDLING

For protection purpose Frequency Inverters Series FU2000 are crated in heavy-duty cardboard boxes with cushioning inserts.




Maximum ambient conditions in storage areas acc. to VDE0160:


- Storage temperature:
-10 °C ... +55 °C
(14 ... 130 °F)
- Relative humidity:
90%, non-dewing



Shipments include:
1. Frequency Inverter
2. Operation Manual



Please study the Operation Manual before attempting any Installation and/or Start-up activities !




ATTENTION:
Shipments must be checked upon receipt for Quality, Quantity and Type. External damages of crating or contents should be reported to LUST at once.

INSTRUCTIONS FOR MECHANICAL INSTALLATION


4.1

OVER-ALL DIMENSIONS, BORE PATTERNS


**Illustration of: FU2233 and
FU2237**



**Illustration of: FU2239 ,
FU2404 and
FU2408
without
LA2000**



**Illustration of:
FU2239 with LA2000
FU2408 with LA2000**



4.2

TYPE OF HOUSING PROTECTION

Protection Rating for the housing is IP10 acc.to DIN 40050. Accident Prevention Rule VBG4 is followed, i.e. protection against contact with larger body surfaces (such as hands) is provided.

4.3


MOUNTING INSTRUCTIONS

Standard Frequency Inverters Series FU2000 are prepared to be mounted in Control Compartments subjected to flow-through of outside air. The converters are mounted on a panel with 4 screws M4.

The following conditions apply to the mounting location:

- Vertical device orientation
- Max. temperature of inflowing cooling air: 40°C
- Rel. humidity: 0 ... 90%, non-dewing
- Max. elevation: 2500m (Performance reduction above 1000m)
- Max. cooling block temperature: 80°C (176°F)

MINIMUM SPACING



ATTENTION:
Mounting Location must
be free of excessive
moisture and of conductive,
and/or aggressive
agents.

- 6** Plug venting attachment's
conduits on pins of the in-
verter's master PCB.




ATTENTION:
Observe polarity!
Red to XLU1+.
Blue/black to XLU2-.

- 7** Double-check correct wiring;
Place and secure cover on
Inverter.

- 8** Switch Inverter ON: Ascertain
that venting fan does NOT
run.

MOUNTING OF VENTING
ATTACHMENT LA2000

CAUTION:
Disconnect Inverter from
power source prior to
performing the following
activities!


stration of Venting
achment

Frequency inverters can be fitted with an LA2000 fan kit to improve cooling to suit the specific application (ambient temperature/operating frequency).

Please proceed as follows:

- 1** Disconnect inverter from power source, then wait appr. 3 minutes to allow the capacitors in the intermediate circuit to discharge completely.
- 2** Remove cover from Inverter.
- 3** Place venting attachment on the inverter's cooling block in such fashion that electrical wiring can be performed on the front.
- 4** Connect venting attachment on cooling block using two self-threading screws (8mm long, in accessories).
- 5** Connect protective (Ground) conduit to inverter housing's ground terminal (ref. to wiring diagram).

Mechanical Installation



Plug venting attachment's
power supply conduits on
pins of master PCB
(XLU1+ red)
(XLU2- blue/black)

INSTRUCTIONS FOR ELECTRICAL INSTALLATION

5.1

RULES AND REGULATIONS

General rules pertaining to the installation of electrical equipment must be followed:

VDE 0100

Rules for High-Voltage Equipment up to 1000V.

VDE 0113

Rules for electrical devices of machining and manufacturing equipment.

VDE 0160

Electronic devices on High-Voltage equipment.

Additional rules and regulations may apply depending upon specific application of the equipment.



Hints for the Prevention of Accidents:

Do not enter the inverter compartment nor touch any components, and delay utilization of measuring instrumentation until the capacitors of the intermediate circuitry are fully discharged (observe yellow LED); ref. to item 19 of 'Lay-out Diagram' in front of manual.

Do not attempt to inspect voltage stability of the device, and disconnect line power supply prior to insulation testing.

The separation of potential of power part and control part is not in accordance with VDE rules relating to low voltage devices.

Leakage current is >3,5mA, requiring hard wiring in accordance with VDE 0160.



Wait
2 minutes!

ATTENTION:

Disconnect line power supply prior to entering the inverter's compartment. Wait 2 minutes (for discharge of the intermediate circuitry's capacitors to less than 65V) before performing any work on the device.

PROTECTIVE MEASURES

Leakage current of the inverter, without cables, is appr. 10mA. Depending upon local rules and regulations the following measures can be taken:



- Protective wiring against false currents
- Protective wiring against false voltages
- Protective grounding
- Protective 'Zero'ing
- Protective conductor system



NOTE:

Protective circuits against false current (FI) can be operated conditionally in conjunction with frequency inverters; however, this is prohibited in some countries.

There are two reasons:



- a) All rectifier loads (i.e. not only those on frequency inverters) could generate a direct current (DC) in the supply power network, which would reduce the protective wiring's effectiveness.

- b) An FI overload switch could be tripped prematurely by radio interference filters, resulting in undesired drive interruption.

CONTROL DEVICES

According to VDE rules, Frequency Inverters must be connected to the power supply line in such fashion, that provisions for total disconnection is provided (such as main breaker switches, relays, or power-operated switches etc.). The motor controlled by the Frequency Inverter can be disconnectable via relay or motor overload switch.



ATTENTION:

Add-on of excited motors, reversal of polar circuitry on pole-reversible motors, and/or reversal of the motor's rotational direction (e.g. via reversal relay) during operation is prohibited.

LISTING OF FUSES

Type	Fuse	FU2233 to FU2408
		30 A FF / 600 V
Intermed. Circuit (11)*		10 x 38

* Ref. to 'Lay-out Diagram' in front of manual.

CABLE ROUTING

Wiring of line power supply, motor power supply and control wiring must be routed in separate cable harnesses.

It is recommended to use shielded cable for control wiring. Shielding must be connected to the inverter only.


Radio interference proofing should be provided as a precautionary measure, e.g. installation of RC-members on relay solenoids.

Instantaneous changes of potential within the motor coils could occur when operating DS motors via Frequency Inverter. Such changes of potential could generate high-frequency currents with negative consequences on other equipment. If such interferences are expected, shielded cable should be provided for motor wiring also. Shielding must be connected to terminal X1/PE.

ELECTRICAL CONNECTIONS

LAY-OUT AND LOCATION DIAGRAM

Please open the front fold-out, containing Lay-out and Location Diagram of the frequency inverter, for the study of the following chapters of this manual.




6.1

POWER TERMINALS (X1)

6.1.1

POWER SUPPLY CONNECTION FU2230

L1	N	PE	PE	U	V	W	-	+
----	---	----	----	---	---	---	---	---




CAUTION:
A delay of 60 seconds Minimum must be observed between switching OFF and switching ON of the Frequency Inverter.

6.1.2

POWER SUPPLY CONNECTION FU2400

L1	L2	L3	PE	PE	U	V	W	-	+
----	----	----	----	----	---	---	---	---	---



CAUTION:
A delay of 60 seconds Minimum must be observed between switching OFF and switching ON of the Frequency Inverter.

Type	Wire Gauge mm ²	Line Fuses A
FU2233	2,5	10
FU2237	2,5	10
FU2239	2,5	16

The following data applies to the power supply network:

Voltage	1 x 230V
Permiss. Line Voltage Fluctuation	-30 / +15%
Permissible Line Voltage Asymmetry	≤ 3%
Network Frequency	50 - 60Hz




CAUTION:
NEVER connect 380/415 VAC on terminals X1/L1 and X1/N!

Type	Wire Gauge mm ²	Line Fuses A
FU2404	2,5	10
FU2408	2,5	10

The following data applies to the power supply network:

Voltage	3 x 400V
Permiss. Line Voltage Fluctuation	-20 / +15%
Permissible Line Voltage Asymmetry	≤ 3%
Network Frequency	50 - 60Hz

6.1.3

MOTOR CONNECTION
FU2230

Power supply to the motor must be connected to terminals X1/ PE, U, V, and W.

Wire gauge must be chosen in correspondence to the expected continuous current rating.

CAUTION:
Standard AC motors 220/380V must be internally wired in „DELTA“ 220V fashion.


NOTE:

For multiple-motor operation care must be taken not to exceed the Frequency Inverter's maximum current rating.



Frequency Inverter	max. Wire Gauge	Continuous Current max.	Motor Rating (4-pole Motor)
Model	mm ²	A	kW
FU2233	2,5	3,8	0,75
FU2237	2,5	6,8	1,5
FU2239	2,5	10,5	2,2

6.1.4

MOTOR CONNECTION
FU2400

Power supply to the motor must be connected to terminals X1/ PE, U, V, and W.

Wire gauge must be chosen in correspondence to the expected continuous current rating.

CAUTION:
Standard AC motors 380/660V must be internally wired in „DELTA“ 380V fashion.

NOTE:

For multiple-motor operation care must be taken not to exceed the Frequency Inverter's maximum current rating.



Frequency Inverter	max. Wire Gauge	Continuous Current max.	Motor Rating (4-pole Motor)
Model	mm ²	A	kW
FU2404	2,5	3,8	1,5
FU2408	2,5	5,5	2,2
FU2408 with LA2000	2,5	7,9	3,0




ATTENTION:
The type of load must be resistive/inductive; capacitive loads are not permitted.
Add-on of excited motors, reversal of polar circuitry on pole-reversible motors, and/or reversal of the motor's rotational direction (e.g. via reversal relay) during operation is prohibited.



ATTENTION:
The type of load must be resistive/inductive; capacitive loads are not permitted.
Add-on of excited motors, reversal of polar circuitry on pole-reversible motors, and/or reversal of the motor's rotational direction (e.g. via reversal relay) during operation is prohibited.

6.1.5


BRAKE CHOPPER TERMINALS (X1)



If the rotor speed (RPM) is higher than the corresponding synchronous speed, energy feed-back into the Frequency Inverter takes place. In this operation mode the motor is subjected to electrical braking action by the Frequency Inverter.

For trouble-free braking operation an external brake chopper should be provided, depending upon the degree of required braking energy.

Installation of an External Brake Chopper:



- 1 Inverter must be disconnected from power source.
- 2 The intermediate circuit's capacitors must be totally discharged, i.e. 0VDC must be present on terminals X1-/ X1+.
- 3 The external brake chopper must be connected to terminals X1-/ X1+.



Wait
2 minutes!

CAUTION:



The Frequency Inverter's power supply must be disconnected prior to performing any work on internal terminals. A delay of 2 minutes from switch-OFF to opening of the compartment must be observed, in order to allow discharge of the capacitors to a voltage below 65V.

6.1.6

RETROFITTING AN INTERNAL BRAKING RESISTOR
RB2239/2400


The FU2239 Frequency Inverter and the FU2400 Frequency Inverter can both, depending on the braking energy, be fitted with an internal braking resistor at a later date.

When fitting the FU2239/2400 resistor please proceed as follows:



- 1 Disconnect inverter from mains supply and wait about 3 minutes to allow the intermediate circuit capacitors to discharge;

FU2000 motherboard



- 2 Remove cover of frequency inverter;
- 3 Insert braking resistor in the recess in the heat sink;
- 4 Close off by pressing in the sleeve;
- 5 Connect braking resistor to motherboard. Connect one load to XR13+ and the other to XR13- (no polarity constraints);

6 Check connections, replace cover;

7 Switch on mains supply to inverter and observe LED 13 (see diagram) to check operation.

Note:

Use: RB2239 resistor for FU2239. RB2400 resistor for FU2404/2408.



Thermostat specifications

Contacts	silver
Switching capacity	10 (6)A, 250V AC (DC)
Operating cycles	1000
Minimum temperature	1°C/min.
Change rate	
Switching point	160°C
Differential	10 ... 20°C

6.1.7

RETROFITTING AN EXTERNAL BRAKING RESISTOR RBC2230 / RBC2400

The FU2239 Frequency Inverter and the FU2400 Frequency Inverter can both, depending on the braking energy, be fitted with an external braking resistor at a later date.

When fitting the RBC2230/RBC2400 resistor please proceed as follows:

1 Disconnect inverter from mains supply and wait about 3 minutes to allow the intermediate circuit capacitors to discharge;

2 Remove cover of frequency inverter;

3 Fit braking resistor to the side of the FU2000 (see diagram);

4 Connect braking resistor to motherboard. Connect one load to XR13+ and the other to XR13- (no polarity constraints);

5 Connect grounding conductor;

6 Connect the thermostatic switch i.e. connect the control safety circuit.

I2000 motherboard




Caution:
The connecting cable must be able to withstand 200°C.

7 Check connections, Replace cover;


8 Switch on mains supply to inverter and observe LED 13 (see diagram) to check operation.

Note:

Use:
RBC2230 resistor for FU2233/2237/2239.
RBC2240 resistor for FU2404/2408.




View X



Connection for thermostatic switch


LAY-OUT DIAGRAM FOR FU2000




- | | |
|-------------------------------------|---|
| 1 Power Supply Terminals (X1) | 10 Pre-Load Relay |
| 2 Motor Connection Terminals (X1) | 11 Fuse for Intermediate Circuitry |
| 3 External brake chopper port | 12 Jumper Strip X11 for Adaptation of Signal 'Nominal Frequency Value' |
| 4 Control Circuit Terminals X2 | 13 LED (yellow) for Intermediate Circuit and Application of Brake Chopper |
| 5 Serial Interface RS485 | 14 Probing Point for max. internal Temperature of Converter |
| 6 Potentiometer (ILIM) | 15 Option LA2000 fan kit |
| 7 LED Display | 16 Digital Control Unit (DBE) |
| 8 Plug Location MC-Print | |
| 9 Intermediate Circuit's Capacitors | |

DIAGRAM OF
WIRING TERMINALS

ATTENTION:
It is recommended to use
shielded cable for control
wiring.



6.2.1

ABBREVIATED CODE FOR
CONTROL TERMINALS

Type of Information *

Direction of Information Flow *

Contents of Information

Type of Information *
A = Analogous Signal
D = Digital Signal (High,Low,States)
F = Pulse frequency signal
R = Contact signal (Relay Output)

Direction of Information Flow *
IN = INPUT
OUT = OUTPUT

Contents of Information
F = Rot.Field Frequency on Inverter Output
FS = Nominal Frequency Value
V = Voltage on Inverter Output
I = Current on Inverter Output

- Standard Control Inputs apply if Direction of information flow is not indicated.
- Indication of type and direction of information is omitted if Output or Input information is displayed on a central operation unit.
- An Input or Output is programmable if the corresponding control terminal is denominated 'Special' input or output.

* does not appear on Display



NOTE:
It is recommended to use shielded cable for control wiring.

Connection Group	Specification
Supply Voltages	<ul style="list-style-type: none"> +10V ±2% NOT short circuit-proof, max. load, 2mA at 5kΩ +22V ±5% NOT short circuit-proof, max. load 200mA <div style="background-color: #e0e0e0; padding: 10px;">  <p>ATTENTION: The supply voltage of 22V is required for control inputs and control outputs. It is of importance NOT to exceed the maximum permissible load of 200 mA.</p> </div>
Analogous Input of nominal Frequency Value FSINA (ref. to 6.4.1)	<ul style="list-style-type: none"> Possibility to cascade several inverters via nominal voltage value Solution 8 BIT Scanning cycle 8msec. Software filter 50msec.
Digital Input of nominal Frequency Value FSINA(F) (ref. to 6.4.2)	<ul style="list-style-type: none"> 'Schmitt'-Trigger input LOW < 4V HIGH > 5V (max. 10V) Limits $F_{MAX} = 1\text{kHz}$ or $F_{MAX} = 10\text{kHz}$ Scanning cycle 8msec. Hardware filter 22msec. Software filter 50msec.

Connection Group	Specification
Digital Control Inputs (S1IND, S2IND, STR; STL)	<ul style="list-style-type: none"> LOW < 3V HIGH > 8V (max. 30V) (other voltages are not permitted) Current on contacts 10mA PLC-Compatible, +24V logical circuit against 'Zero' Scanning cycle 8msec. Hardware filter 3,3msec. Software filter 2 x Scanning cycle
Digital Control Outputs (S1OUT, S2OUT, S3OUT)	<ul style="list-style-type: none"> Programmable function 1 driver output (S1OUT), short circuit-proof, 80mA maximum, HIGH activated 2 open collector outputs (S2OUT, S3OUT), NOT short circuit-proof, 50mA maximum, LOW activated, internally pulling 10kΩ at 22V
Digital Frequency Output (FOUTF)	<ul style="list-style-type: none"> NOT short-circuit-proof, constant pulse width appr. 400μs-LOW output frequency 6-fold, HIGH at stop = 22V to connection of DF40/56
Analogous Output (SOUTA)	<ul style="list-style-type: none"> NOT short circuit-proof, output voltage 10V with 50% overvoltage max. load 1mA Solution 7 BIT

6.4

CONTROL FUNCTIONS

6.4.1

ANALOGOUS ENTRY OF NOMINAL FREQUENCY VALUE (FSINA(F))



Potentiometer

 $R_i = 100\text{k}\Omega$

Ratio:

(against X2 : 22)
0k Ω = fmin
10k Ω = fmax

X11 Jumper position A



External 0 ... (2) ... 10V

 $R_i = 100\text{k}\Omega$

Ratio:

(against X2 : 22)
0V (0V; 2V) = fmin
10V (2V; 10V) = fmax

X11 Jumper positions:

A: 0 ... 10V

D: 0 ... 2V

E: 2 ... 10V

External 0 (4) ... 20mA

 $R_i = 500\Omega$

Ratio:

(against X2 : 22)
0 (4)mA = fmin
20mA = fmax

X11 Jumper position

B = 0 ... 20mA

C = 4 ... 20mA

NOTE:

The location of jumper strip X11 is shown on the front fold-out of this manual.

With preselected rotational direction the inverter can also be started via nominal frequency value input.

FSINA(F)	Meaning
$FS > \frac{F_{MAX}}{64}$	START
$FS < \frac{F_{MAX}}{128}$	STOP

6.4.2


DIGITAL ENTRY OF NOMINAL FREQUENCY VALUE (FSINA(F))

 $R_i = 100\text{k}\Omega$

Ratio:

(against X2 : 22)
0kHz = fmin
1(10)kHz = fmaxLOW < 4V
HIGH > 5V (max. 10V)

X11 Jumper position A




NOTE:

Reversal from analogous to digital nominal value is performed via digital control unit. Digital and analogous control preclude each other.

TABLE OF CONTROL FUNCTIONS 'RH START', 'LH START', 'REVERSAL' AND 'RAMP-CONTROLLED BRAKE APPLICATION'

STL	STR	Reaction
0	0	OFF
0	1	RH (Clockw.)
1	0	LH (Ct.Clockw.)
1	1	Braking



PRECONDITION	ACTION / ACTUATION	REACTION / ABLAUF
RH START		
<ul style="list-style-type: none"> Main switch ON No Malfunction Nominal Value entered 	<ul style="list-style-type: none"> Enter STR 	<ul style="list-style-type: none"> Output stages released Rotational Field in RH (Clockw.) direction Inverter's output frequency accelerates along preselected ramp to preselected nominal frequency value
	<ul style="list-style-type: none"> Clear STR 	<ul style="list-style-type: none"> Output stages closed Motor coasts out without control
LH START		
<ul style="list-style-type: none"> Main Switch ON No Malfunction Nominal Value entered 	<ul style="list-style-type: none"> Enter STL 	<ul style="list-style-type: none"> Output stages released Rotational Field in LH (Ct. Clockw.) direction Inverter's output frequency accelerates along preselected ramp to preselected nominal value
	<ul style="list-style-type: none"> Clear STL 	<ul style="list-style-type: none"> Output stages closed Motor coasts out without control
REVERSAL		
<ul style="list-style-type: none"> Main Switch ON No Malfunction Nominal Value entered STR entered 	<ul style="list-style-type: none"> Enter STL Clear STR 	<ul style="list-style-type: none"> Inverter decelerates from operational frequency down to '0' along preselected ramp; Change from RH (Clockw.) to LH (Ct. Clockw.) Field rotation; Inverter then accelerates its output frequency along pre-selected acceleration ramp to nominal value.
<ul style="list-style-type: none"> Main Switch ON No Malfunction Nominal Value entered STL entered 	<ul style="list-style-type: none"> Enter STR Clear STL 	<ul style="list-style-type: none"> Inverter decelerates from operational frequency down to '0' along preselected ramp Change from LH (Ct. Clockw.) to RH (Clockw.) Field rotation Inverter then accelerates its output frequency along pre-selected acceleration ramp to nominal value
	ATTENTION: STR and STL must be actuated in overlapping fashion.	
RAMP-CONTROLLED BRAKING		
<ul style="list-style-type: none"> Main Switch ON No Malfunction Nominal Value entered STR or STL entered 	<ul style="list-style-type: none"> Enter opposite direction; both, RH and LH direction must be entered. 	<ul style="list-style-type: none"> Inverter decelerates its output frequency along preselected ramp, subsequently closing its output stages.

Control Level					Page	Setting Range	Factory Setting	Customer Setting
No.1	No.2	Abbr.	Dim.	Parameter Name				
01	01	MODE	-	Operation Mode	28	1 ... 6	1	
	04	FSSEL	-	Selector for Nominal Frequency Value	32	0 ... 23	0	
Modes (Display only)								
12	F	Hz		Output Frequency	32	0 ... 400		
13	V	%		Output Voltage	32	0 ... 100, from U _{line}		
18	TIME	h		Switch-ON after Reset	32	0 ... 960	4	
19	TOP	h		Operation Hours	32	0 ... 65000	4	
Frequencies								
21	21	FMIN	Hz	Minimum Frequency	28	0 ... 400	0	
22	22	FMAX	Hz	Maximum Frequency	28	4 ... 400	50	
23	23	FF2	Hz	Fixed Frequency	29	0 ... 400	5	
24	24	FF3	Hz	Fixed Frequency	29	0 ... 400	0	
25	25	FF4	Hz	Fixed Frequency	29	0 ... 400	60	
26	26	FF5	Hz	Reference Frequency for S2OUT	29	0 ... 400	3	
27	FF6	Hz		Control Frequ. Selector for U/f Curve Set	33	0 ... 400	0	
28	FF7	Hz		Fixed Frequency (Program. via Option. Function)		0 ... 400		
Ramps								
31	KSEL	-		U/f Curve Set Selector	33	0 ... 3	0	
32	32	RACC1	Hz/sec	Acceleration Ramp 1*	29	0,1 ... 999	20	
33	33	RDEC1	Hz/sec	Deceleration Ramp 1*	29	0,1 ... 999	20	
34	RACC2	Hz/sec		Acceleration Ramp 2*	33	0,1 ... 999	80	
35	RDEC2	Hz/sec		Deceleration Ramp 2*	33	0,1 ... 999	80	
36	36	RSTOP	Hz/sec	STOP Deceleration Ramp	30	0 ... 999	0 = OFF	
	38	THTDC	sec	OFF Delay of DC Stop Torque	34	0 ... 5	0 = OFF	
	39	VHTDC	%	DC Stop Voltage	34	1,0 ... 15	3	
U/f Curve								
41	41	V/F C	-	U/f Curve Selector	30	0 ... 5	0	
42	42	VB1	%	Start Torque (Boost 1)*	30	0 ... 25, from U _{line}	5	
43	FN1	Hz		Nominal Frequency Point 1*	31	26 ... 960	50	
44	VB2	%		Start Torque 2 (Boost 2)*	33	0 ... 25, from U _{line}	5	
45	FN2	Hz		Nominal Frequency Point 2*	33	26 ... 960	50	
Current Boundary Value								
56	TRIP	%		Overload Protection	34	0 ... 3	0	
Control Circuit								
61	SOUTA	-		Programming of Analogous Output	35	0 ... 3	1	
62	S1OUT	-		Programming of Control Output 1	35	0 ... 10	1	
63	S2OUT	-		Programming of Control Output 2	35	0 ... 10	7	
64	S3OUT	-		Programming of Control Output 3	35	0 ... 10	6	
Program								
71	PROG	-		Program No.	36	0 ... 9999	0	
72	72	START	-	Start Option	31	0 ... 7	0	
	74	PWM	-	Modulation Frequency.	36	0 ... 1	0	
Converter Data								
95	ERR 1	-		Last Failure	36	F00 ... 99		
96	ERR 2	-		Next to last Failure	36	F00 ... 99		
97	ERR 3	-		Second to last Failure	36	F00 ... 99		
98	ERR 4	-		Third to last Failure	36	F00 ... 99		

Use parameters can be reserved in correlation to the U/f Curve Set Selector (Parameter No. 31).

6.4.4

SWITCHING „ON“ MAIN POWER SUPPLY VIA STL OR STR

For safety reason the Inverter must not be switched ON while control function STL (or STR) is activated.

If the Frequency Inverter is switched ON (connected to power supply network) while STR or STL is activated, it ignores the start condition until such time that both, RH and LH control contacts are on 'OFF' (Stop) simultaneously.



NOTE:

Activation of function 'AUTOSTART' precludes the behavior described above.



ATTENTION:

Your attention is drawn to VDE rules 0100, part 227 and rule 0113, especially paragraph 5.4, concerning protection against undesired automatic restart after power failure and restoration of voltage, as well as paragraph 5.5, concerning protection against sub-voltage. Jeopardizing personnel, machines and/or production goods must be avoided. Other rules and regulations pertaining to the specific operation must also be followed.

6.4.5

RESET

The Frequency Inverter resumes 'Ready' mode after having been in 'Failure' mode, if the malfunction no longer exists, and if the main switch is switched 'OFF' and then 'ON'.



OTE:

Iteration of parameters 31-EL, 23-FF2, 24-FF3, and 25- is possible via DBE or via serial interface (ref.to chapter 8).


S2IND	S1IND	KSEL ≠ 2	KSEL = 2
0	0	FSINA(F) , U/F Curve set 1	FSINA (F) , U/F Curve set 1
0	1	FF2 , U/F Curve set 1	FF2 , U/F Curve set 1
1	0	FF3 , U/F Curve set 1	FSINA (F) , U/F Curve set 2
1	1	FF4 , U/F Curve set 1	FF2 , U/F Curve set 2

TABLE OF CONTROL FUNCTION 'FREQUENCY REVERSAL'




OTE:

Direct reversal from fixed frequency to nominal frequency resp., and vice-versa, is permitted (ref.to example 'Frequency Reversal').



PRECONDITION	ACTION / ACTUATION	REACTION / PROCESS
Activation of Fixed Frequency 2 (3) / FF2 (FF3)		
<ul style="list-style-type: none"> Main switch ON No Malfunction KSEL ≠ 2 STL or STR ON 	<ul style="list-style-type: none"> Enter S1IND (S2IND) 	<ul style="list-style-type: none"> The Frequency Inverter's output frequency is decelerated or accelerated, resp., to the frequency programmed in FF2 (FF3), along the preselected acceleration ramp or deceleration ramp, resp..
Activation of Fixed Frequency 4 / FF4		
<ul style="list-style-type: none"> Main switch ON No Malfunction KSEL ≠ 2 STL or STR ON 	<ul style="list-style-type: none"> Enter S1IND and S2IND 	<ul style="list-style-type: none"> The Frequency Inverter's output frequency is decelerated or accelerated, resp., to the frequency programmed in FF4, along the preselected acceleration ramp or deceleration ramp, resp..



Example: Frequency Reversal (KSEL ≠ 2)


TABLE OF CONTROL FUNCTIONS 'U/F CURVE REVERSAL' AND 'RAMP REVERSAL'

PRECONDITION	ACTION / ACTUATION	REACTION / PROCESS
U/F Curve Reversal in 'Stop' Mode		
<ul style="list-style-type: none"> Main Switch ON No Malfunction KSEL = 2 STL and STR OFF (End Stages closed) 	<ul style="list-style-type: none"> Enter S2IND 	<ul style="list-style-type: none"> The Frequency Inverter reverses from U/F Curve set 1 to U/F Curve set 2.
Ramp Reversal in 'Stop' Mode or in 'Run' Mode		
<ul style="list-style-type: none"> Main Switch ON No Malfunction KSEL = 2 FN1 = FN2 STR or STL ON 	<ul style="list-style-type: none"> Enter S2IND 	<ul style="list-style-type: none"> The Frequency Inverter reverses from the ramp pair selected in U/F Curve set 1 to the ramp pair selected in U/F Curve set 2 (ref. to example below).

ATTENTION:
U/F Curve reversal during operation is not permitted.

Direct reversal from Ramp pair 1 to ramp pair 2 during operation is permissible only if parameters FN1 and FN2 are set identically.

U/F Curve set 1	U/F Curve set 2
RACC1	RACC2
RDEC1	RDEC2
VB1	VB2
FN1	FN2



Example: Ramp Reversal (KSEL = 2)

6.5

PROGRAMMABLE DIGITAL CONTROL OUTPUTS (S1OUT-S3OUT)

6.5.1


CONTROL OUTPUT 1 S1OUT:

Specification:

- Short Circuit-Proof
- Max. Current Load: 80mA
- Output Voltage: 20V
- HIGH activated
- Internal recovery diode for relay control
- Basic Setting:
S1OUT = 1
Failure Summary Message

Explanation:

The cable-break-proof signal output is deactivated if the rotational field's frequency has surpassed the value programmed in 'Fixed Frequency' FF5 ($F > FF5$).



6.5.2

CONTROL OUTPUT 2 AND 3 S2OUT, S3OUT:



ATTENTION :

Signal outputs 2 and 3 (S2OUT/S3OUT) are NOT short circuit-proof; max. current load: 50mA


Specification:

- NOT Short Circuit-proof
- Max. Current Load: 50mA
- Output Voltage: 22V
- LOW activated (< 1,5V)
- Basic Setting:
S2OUT = 7
Operation Message
S3OUT = 6
Nominal Frequency Value reached

Explanation S2OUT:


Signal output 2 is activated,

- if main power supply is disconnected, or
- if the Inverter is switched OFF with Failure Display



Explanation S3OUT:

Signal output 3 is activated, if the rotational field's frequency has reached the preselected nominal value (FS).
($F = FS \pm 0,5\text{Hz}$)



Programming Options:

S1OUT S2OUT S3OUT	MEANING	EXPLANATION
0	-	Output deactivated
1 (S1OUT)*	Failure Summary Message	Deactivated if Frequ. Inv. is de-energized due to a failure
2	Motor Output activated	Activated if motor is excited
3	Ct-Clockw. (LH) Direction	Activated if STL and nominal value or stop torque is entered
4	Clockw. (RH) Direction	Activated if STR and nominal value or stop torque is entered
5	Motor Stop	Activated if rotational field's frequency is 0Hz (Stop Torque)
6 (S3OUT)*	Nominal Frequency Value reached	Activated if nominal speed (RPM) is reached ($F = FS \pm 0,5\text{Hz}$)
7 (S2OUT)*	Frequency Boundary Value	Activated if rotational field's frequency has surpassed the fixed frequency programmed in FF5 ($F > FF5$)
8	Current Boundary reached	Activated if actual current boundary value is exceeded ($IW > ILIM$)
9	Brake chopper activated	Activated if brake chopper on
10	Failure Stop	Activated if Frequency Inverter is de-energized due to a failure


* Basic Setting

6.6

PROGRAMMABLE ANALOGOUS OUTPUT (SOUTA)



ATTENTION:
The programmable output SOUTA is NOT short circuit-proof; max. current load: 1mA



Specification:

- NOT Short Circuit-Proof
- Max. Current Load: 1mA
- Output Voltage: 10V + 50% Overvoltage (max.15V)
- Programmable via DBE
- Tolerance \pm 5%
- Solution 7 BIT
- Basic Setting:
SOUTA = 1
Display of rot.field's frequency
(50Hz = 10V)

Explanation:

The 15V are output corresponding to the 7 BIT in 126 increments of 120mV per increment.

PROGRAMMING POSSIBILITIES


SOUTA	Function	Ratio	max. Value
0	Deactivated	-	-
1	Rot. Field Frequ.	50Hz \triangleq 10V	75Hz
2	Rot. Field Frequ.	100Hz \triangleq 10V	150Hz
3	Rot. Field Frequ.	500Hz \triangleq 10V	400Hz
4	Motor Voltage	100% \triangleq 10V	150%

6.7

FREQUENCY OUTPUT (FOUTF)




ATTENTION:
The Frequency Output FOUTF is NOT short circuit-proof; max. current load: 50mA



Specification:

- NOT Short-Circuit-Proof
- Max. Current Load 50mA
- Output Voltage (HIGH level) 22V
- 6-fold Rot.Field Frequency
- Open Collector (LOW activated)
- LOW pulse constant 400µs



Explanation:

6 LOW pulses are output on the frequency output for each 1Hz frequency of the rot. field.



Note:


The frequency output is prepared for connection of DF40/56.

SERIAL INTERFACE RS485



ATTENTION:
The serial interface RS485 is active only with the FU2000-RT!

Frequency Inverters are subjected to communication with primary control and monitoring systems at an ever increasing rate. Serial interfaces transmit data, free of interference, without detouring via Digital/Analogous conversion (D/A Inverter). Up to 30 Frequency Inverters can be controlled, monitored and supplied with parameter entries by ONE Central Master Computer. Digital data transmission performs bi-directionally. Data transmitted to the frequency inverter are confirmed, or automatically repeated if transmission errors take place. Operational mode, e.g. RH or LH drive, or data such as motor current, motor voltage, frequency etc., can be scanned continuously. The frequency inverter's parameters can be monitored and altered, and failure messages can be put on display.



ATTRIBUTES OF THE BUS SYSTEM

Transmission Medium	RS485: 2-wire cable twisted and shielded, with end resistance
Bus Access	Linear, centrally controlled by Master
Transmission Speed	9600 Bits/Second
Transmission Format	8 Bits asynchronous with Start/Stop Bits
Transmission Distance	max. 1000m
Participants	30 Frequency Inverters 1 Master
Failure Recognition	Length and Cross parity, Reasonability
Data Print-out	Based upon ISO Standard 1745
Broadcast Message	The Broadcast Message is directed to all frequency inverters and facilitates synchronized signal transmission.



NOTE:
Detailed information in regard to data print-out is available from

LUST electronic
systeme


LUST Electronic-Systeme GmbH
Gewerbestraße 5-9
D-6335 Lahnau 1

Phone 0 64 41 / 6 02-0
Telefax 0 64 41 / 6 02-37

or from foreign sales agencies.

ENTRY OF PARAMETERS VIA DIGITAL CONTROL UNIT (DBE)

FUNCTIONAL DESCRIPTION



Entry of parameters takes place via the Digital Control (Bedien) Unit (abbr.'DBE'), which is integrated in the Inverter. Integration of 'DBE' resulted in the following advantages:


- 1** Continuous availability of the Inverter (use of potentiometers discontinued)
- 2** Ease of Operation
- 3** Simplified handling
- 4** High-degree reproducibility of parameter setting due to digital control structure.

LCD DISPLAY

The 5-Digits LCD Display used can signal the following inverter modes:

- 1** **Self-Test**
Upon connecting the inverter to the power supply source the display reads 'TEST' for the duration of appr. 2-3 seconds.
- 2** **Ready to Operate**
Upon completed self-test the inverter assumes 'READY' mode.
- 3** **Inverter ON**
Via RH or LH Start (STR/STL) the inverter accelerates to the selected nominal frequency value (e.g. 50 Hz).
- 4** **Failure Mode**
Failure Messages are shown in coded fashion, e.g. 'ERR 11' = Switched OFF due to overload.
- 5** **Parameter Display**
The inverter's parameters are displayed in coded fashion, showing first the parameter number, and following the colon(:) the parameter's value (ref.to listing of parameters in chapter 10.2).

Parameter No. Parameter Value

**OPERATION**

- LED 'STOP' glows:
Power Supply is ON,
inverter in Stop mode
(Ready for operation).
- LED 'RUN' glows:
Inverter in Operation
(Output to motor activated).

MALFUNCTION (FAILURE)

- LED 'STOP', or LED 'RUN'
flashing:
Ref. to Evaluation of LED
Display (Chapter 9.3).
- Display indicates Failure
Code.
- Failure has been registered.

CONTROL COMPONENTS FOR PARAMETER ENTRY**'DOWN' KEY / 'UP' KEY**


- The 'UP' and 'DOWN' keys are used to select menu points within one menu level, via up and down 'scrolling'.
- They also alter numeric values, again via up and down 'scrolling'.
- When actuated simultaneously, these keys are used to scan basic settings.

**'TRANSFER' ('ENTER') KEY**

- Via first actuation of the 'Transfer' key the system is placed in 'Alteration' mode, i.e. the mode for alteration of parameters.
- Via second actuation of this key the altered parameter is 'Entered' into storage.

The menu provides 3 control levels.

Parameters essential for Start-up are noted in level 1. This level is of the single-stage type for 'direct' alteration of parameter values.



Conception of Control Levels


In addition to the possibility of parameter alteration in level 1, additional parameters and some 'special' functions are provided in level 2, such as 'slippage compensation'. This control level is of the multi-stage type. Selection of the desired parameter block is made on stage 1; the actual entry of the individual parameter alteration is made on stage 2 (ref.to diagram of menu structure of level 2 , shown at the end of this manual).

Level 3 is provided exclusively for interface operation, e.g. entry of the 'Slave' address, surveillance of bit combinations, etc.).

7.2.1

PASSWORD

In order to prevent manipulation and possible alteration of parameters by unauthorized personnel, a three-digit password must be entered after initial entry of the alteration mode.




Password prompting takes place prior to initial entry of parameters (Display Colon (:) flashes).

Depress and hold 'UP' key until the required password number is on display.




Actuate ENTER key to confirm password.

Upon correct entry of the password, parameter entry is permitted for the duration of 10 minutes. After expiration, or when depressing and holding the ENTER key for 3 seconds, the alteration mode is again interlocked.



Upon accepting the password the last previous parameter selected appears on display (e.g. 'Fmax' = maximum frequency).



If the password is not accepted (wrong password or wrongly entered), an ERRor message is displayed.



ATTENTION:
The Standard Password (Factory-set) is indicated at the end of this manual (ref. to chapter 10).


7.2.2

ENTRY OF PARAMETERS

Example of parameter entry for alteration of maximum frequency from 60Hz to 50Hz:




1 Power ON; LCD Display indicates STOP.



2 Briefly actuate UP key.



3 Parameter No.1 is displayed.




4 Briefly actuate UP key twice.




5 Actual value of parameter No.22 „Max.Frequency“ is displayed.



6 Briefly actuate ENTER key; colon (:) following '22' flashes - prompting for password prior to attempting to alter this parameter.



7 Depress and hold DOWN key until



8 „50,0“ Hz is displayed.

9 Briefly actuate ENTER key. Display disappears for an instant, to return after appr. 1 second with the colon (:) no longer flashing.

- 10** The Inverter can be switched ON when entry of the parameter is completed. Display changes automatically to the 'Actual' frequency of the Inverter's rotational field.



ATTENTION:

The display remains on minimum or maximum boundaries if these values are exceeded during parameter setting.




NOTE:

Alteration of parameter values should be performed while the Inverter is in STOP mode.

7.3

7.3.1



CONTROL LEVEL 1 / MENU FOR INITIAL START-UP

SELECTION OF OPERATIONAL MODE

OPERATIONAL MODE 01 - MODE

Possible Entries:

MODE	CONTROL	LEVEL
0	Terminal and SIO	3
1	Terminal	1
2	Terminal	2
3	Terminal	3

Basic Setting = 1

Explanation:

- Parameter MODE allows selection of Control type and access to other menu levels.

7.3.2

FREQUENCIES

MINIMUM FREQUENCY 21 - FMIN




Setting Range:

- FMIN min = 0,0Hz
- FMIN max = 400,0Hz
- Resolution* = 0,1Hz
- Basic Setting = 0,0Hz

Explanation:

- Entry of nominal value 'Zero' corresponds to output frequency FMIN.
- With analogous entry of nominal value the range corresponds, e.g., to 0 ... 10V, FMIN ... FMAX.

MAXIMUM FREQUENCY 22 - FMAX



Setting Range:

- FMAX min = 4,0Hz
- FMAX max = 400,0Hz
- Resolution = 0,1Hz
- Basic Setting = 50,0Hz

Explanation:

- Output frequency is limited to FMAX, i.e. maximum nominal value = FMAX.
- With analogous entry of nominal value the range corresponds, e.g., to 0 ... 10V, FMIN ... FMAX.

* Resolution of DBE (Digital Control Unit)

FIXED FREQUENCIES

- 23 - FF2
- 24 - FF3
- 25 - FF4

23.50

24.00

25.600


Setting Range:

- FFx min = 0,0Hz
- FFx max = 400,0Hz
- Resolution = 0,1Hz
- Basic Setting: FF2 = 5,0Hz
FF3 = 0,0Hz
FF4 = 60,0Hz

Explanation:

S2IND	S1IND	Frequencies
0	0	Entry of Nom. Val. activated
0	1	FF2
1	0	FF3
1	1	FF4

(ref.to chapter 6.4.6)



Fixed Frequencies

CONTROL FREQUENCY 26 - FF5

Setting Range:

- FF5 min = 0,0Hz
- FF5 max = 400,0Hz
- Resolution = 0,1Hz
- Basic Setting = 3,0Hz

26.30

Explanation:

- Programmable digital signal output is activated if the rotational field's frequency surpasses the fixed frequency programmed in FF5 (F > FF5).

7.3.3

RAMPS

ACCELERATION RAMP

- 32 - RACC1


32.200

Setting Range:

- RACC1 min = 0,1Hz/sec
- RACC1 max = 999,0Hz/sec
- Resolution = 0,1Hz/sec
- Basic Setting = 20,0Hz/sec

Explanation:

- Ref. to Diagram: Frequency/Ramp
- Acceleration Time from 0Hz to FMAX



Minimum acceleration time:

$$\frac{FMAX}{RACC} = \frac{50\text{Hz}}{0,1\text{Hz/sec}} = 500\text{sec}$$

Maximum acceleration time:

$$\frac{FMAX}{RACC} = \frac{50\text{Hz}}{20\text{Hz/sec}} = 2,5\text{sec}$$

DECELERATION RAMP 33 - RDEC1

Setting Range:

- RDEC1 min = 0,1Hz/sec
- RDEC1 max = 999,0Hz/sec
- Resolution = 0,1Hz/sec
- Basic Setting = 20,0Hz/sec

33.200

Deceleration time:

$$\frac{FMAX}{RDEC} = \frac{50\text{Hz}}{20\text{Hz/sec}} = 2,5\text{sec}$$

- Ref. to Diagram: Frequency/Ramp




Diagram: Frequency/Ramp



ATTENTION:

The display remains on minimum or maximum boundaries if these values are exceeded during parameter setting.

STOP RAMP 36 - RSTOP



Setting Range:

- RSTOP min = 0,0Hz/sec
- RSTOP max = 999,0Hz/sec
- RSTOP ON = ≥ 0,1Hz/sec
- RSTOP OFF = 0,0Hz/sec
- Basic Setting = 0,0Hz/sec

Precondition	Action / Actuation	Reaction / Process
Stop via RSTOP = 0,0Hz/sec		
"STR" or "STL" - ON	• Cancellation of Entry "STR" and "STL"	1 Output stages locked.
RSTOP = 0		2 Motor 'coasts' out uncontrolled.
Stop via RSTOP ≥ 0,1Hz/sec	"STR" or "STL" - ON RSTOP ≥ 0,1Hz/sec	1 Inverter decelerates its output frequency along selected stop ramp to 0Hz. 2 Output stages locked.

Explanation:

- Ref. to Diagram: Frequency/Ramp



ATTENTION:

Observe possible generator phenomena of motor:
If required, provide brake chopper of adequate dimensioning (ref. to chapter 6.1.5).

Switch-OFF delay THTDC is disabled.

7.3.4

DIAGRAMS

CURVE CHARACTERISTICS



41 - V/F C

Setting Range:


- V/F C min = 0
- V/F C max = 5
- Basic Setting = 0

Explanation:


- ref. to illustrated diagrams




V/F C = 0 linear




V/F C = 3 mixed raised




V/F C = 1 linear raised



V/F C = 4 square



V/F C = 2 mixed



V/F C = 5 square raised

III.: Diagram Characteristics

BOOST (START TORQUE) 42 - VB1

Setting Range:

- VB1 min = 0%
- VB1 max = 25%
- Resolution = 0%
- Basic Setting = 8%

Explanation:

- Selected %-value is always related to line power voltage.
- ref. to III. U/f Curve.



RATED FREQUENCY
43 - FN1

43.500

Setting Range:

- FN1 min = 26,0Hz
- FN1 max = 960,0Hz
- Resolution = 0,1Hz
- Basic Setting = 50,0Hz

Explanation:

- 'Rated Frequency' indicates at which frequency the motor reaches 100% of the power supply's voltage.
- Ref. to ill. 'U/f Curve'.

7.3.5


72 0

START OPTIONS
72 - START


Setting Possibilities:

START	OPTION
0	Standard
1	Autostart
4 \triangleq 0	Standard with LH direction locked-out
5 \triangleq 1	Autostart with LH direction locked-out

Basic Setting = 0



III.: U/f Curve (linear) V/F C = 0



III.: U/f Curve (linear raised) V/F C = 1

Explanation:

Autostart

For safety reason the inverter does not re-start automatically upon power restoration after a power failure. This safety feature, however, can be disabled when activating AUTOSTART (ref. to 6.4), causing automatic re-start upon power restoration.



ATTENTION:

Your attention is drawn to VDE rules 0100, part 227 and rule 0113, especially paragraph 5.4, concerning protection against undesired automatic re-start after power failure and restoration of voltage, as well as paragraph 5.5, concerning protection against sub-voltage. Jeopardizing personnel, machines and/or production goods must be avoided. Other rules and regulations pertaining to the specific operation must also be followed.

Lock-out of LH Rot.Direction

For certain drives (e.g. knitting machines) it is of utmost importance that no directional reversal can occur, even in case of faulty manipulation. This can be ascertained through utilization of parameters 4, 5, 6, and 7. The description of control functions STL and STR remains valid except for function START LH (ANTI-CLOCKWISE).

CONTROL LEVEL 2/ ENTRY OF PARAMETERS FOR OTHER FUNCTIONS

In addition to the parameters for initial start-up in control level 1 more functions can be called up in control level 2 and their parameters can be entered.

Initially a Primary term (Parameter Block) is selected, followed by alterations of parameters in the lower menu level.


As most of the following parameters serve to make settings of complex functions, they are not described individually, they are explained in conjunction with their respective functions.

ENTRY OF NOMINAL VALUE INPUT FSINA(F)

SELECTOR FOR NOMINAL FREQUENCY VALUE 04 - FSSEL

Setting Range:

- FSSEL min = 0
- FSSEL max = 5
- Basic Setting = 0



FSSEL	Nominal Value	Scaling
0	FSINA	0(2)V, 0(4)mA = FMIN (2)10V, 20mA = FMAX
1	FSINA	(2)10V, 20mA = FMIN 0(2)V, 0(4)mA = FMAX
4	FSINF	0kHz = FMIN 1kHz = FMAX
5	FSINF	0kHz = FMIN 10kHz = FMAX

* Depending on Jumper position X11 (ref.to chapter 6.4.2).

Other settings are not permitted.

ENTRY OF ACTUAL VALUE DISPLAY



NOTE:

- The following parameters are for 'READ' only; they facilitate monitoring of the operation via serial interface.


OUTPUT FREQUENCY 12 - F



Explanation:

- Displays actual output frequency.

OUTPUT VOLTAGE 13 - U



Explanation:

- Displays actual output voltage in % of the power supply voltage.

OPERATING TIME




OPERATING HOURS 18 - TIME

Explanation:

- Displays number of operating hours since last switch-ON of system.

TOTAL OPERATION TIME 19 - TOP



Explanation:

- Displays total hours of operation since initial start-up of the equipment (Time clock reading).
- Indicated value remains in memory (EEPROM) after switch-OFF.
- Overflow after 65000 hours.



NOTE:

- Upon selection of parameter No.19 the display changes to operation hours.

ENTRY OF U/f CURVE SETS AND RAMP REVERSAL

ACCELERATION RAMP 2
34 - RACC2

34800

Setting Range:

- RACC2 min = 0,1Hz/sec
- RACC2 max = 999,0Hz/sec
- Resolution = 0,1Hz/sec
- Basic Setting = 80,0Hz/sec

DECELERATION RAMP 2
35 - RDEC2

35800

Setting Range:

- RDEC2 min = 0,1Hz/sec
- RDEC2 max = 999,0Hz/sec
- Resolution = 0,1Hz/sec
- Basic Setting = 80,0Hz/sec

START VOLTAGE 2
44 - VB2

44 80

Setting Range:

- VB2 min = 0,0%
- VB2 max = 25,0%
- Resolution = 0,1%
- Basic Setting = 8,0%

NOMINAL FREQUENCY POINT 2
45 - FN2

45500

Setting Range:

- FN2 min = 26,0Hz
- FN2 max = 960,0Hz
- Resolution = 0,1Hz
- Basic Setting = 50,0Hz

CONTROL FREQUENCY
27 - FF6

27 00

Setting Range:

- FF6 min = 0,0Hz
- FF6 max = 400,0Hz
- Resolution = 0,1Hz
- Basic Setting = 0,0Hz

Explanation:

- If parameter KSEL is set on 1, and the output frequency (control frequency selected via FF6) is surpassed, automatic reversal to U/f curve set 2 takes place (ref.to table and chapter 6.4.8).

SELECTION OF U/F CURVE SET
31 - KSEL

Setting Range:

- | | |
|-----------------|-----|
| • KSEL min | = 0 |
| • KSEL max | = 3 |
| • Basic Setting | = 0 |

Explanation:

- Ref. to table below

31 0

KSEL	U/F Curve Set 1 activated if	U/F Curve Set 2 activated if
0	No Reversal (U/F Curve Set 1 activated)	No Reversal (U/F Curve Set 2 activated)
1	F ≤ FF6	F > FF6
2	S2IND = LOW	S2IND = HIGH
3	RH Rotat. Field	LH Rotat. Field



NOTE:

The following table shows which parameters are allocated to U/F Curve Set 1 or 2.

U/F Curve Set 1	U/F Curve Set 2
RACC1	RACC2
RDEC1	RDEC2
VB1	VB2
FN1	FN2

7.4.5

ENTRY OF DC STOP TORQUE


DC VOLTAGE
39 - VHTDC

Setting Range:

- VHTDC min = 1,0%
- VHTDC max = 15,0%
- Resolution = 0,1%
- Basic Setting = 3,0%

Explanation:

- This percentage value is based on power supply voltage.

DC STOP DELAY TIME
38 - THTDC

Setting Range:

- THTDC min = 0,0sec
- THTDC max = 5,0sec
- THTDC ON = ≥ 0,1sec
- THTDC cont'lly. ON = 5sec
- THTDC OFF = 0,0sec
- Resolution = 0,1sec
- Basic Setting = 0,0sec

Explanation:

- Ref. to table below

Precondition Action / Actuation Reaction / Process

DC STOP TORQUE with Stop Delay

0 < THTDC < 5sec
"STL" and/or "STR" ON

- Frequency Reference "Zero" or
- Braking: "STR" and "STL" ON

- 1 After falling short of output frequency FS < FMAX / 128 the motor is subjected to a DC current corresponding to parameter entry VHTDC.
- 2 The output stage is deactivated upon expiration of the delay time selected with parameter THTDC.

DC STOP TORQUE without Stop Delay

THTDC = 5sec
"STL" and/or "STR" ON

- Frequency Reference "Zero" or
- Braking: "STR" and "STL" ON

- 1 After falling short of output frequency FS < FMAX / 128 the motor is subjected to a DC current corresponding to parameter entry VHTDC.
- 2 The Stop torque remains in effect until the output frequency returns to FS < FMAX / 128, or until the Inverter is set on STOP (STR and STL OFF).

7.4.6

ENTRY OF OVERLOAD PROTECTION

56 - TRIP


Setting Range:

- | | | |
|-----------------|---|---|
| • TRIP min | = | 0 |
| • TRIP max | = | 3 |
| • TRIP ON | = | 0 |
| • TRIP OFF | = | 0 |
| • Basic Setting | = | 0 |



Explanation:

- At TRIP = 0 no switch-OFF takes place when overload occurs; instead, the output frequency is altered in correspondence to the load.
- At TRIP = 1 quick switch-OFF takes place within appr. 10sec.
- At TRIP = 2 medium switch-OFF takes place within appr. 30sec.
- At TRIP = 3 delayed switch-OFF takes place within appr. 100sec.



III.: Max. permissible Overload Surface for 1,5-fold Overload

SPECIFICATION OF SPECIAL OUTPUTS

ANALOGOUS OUTPUT
61 - SOUTA

Setting Range:
• Basic Setting = 1

Possible Settings:

SOUTA	SPECIFICATION
0	non-active
1	F 50Hz ± 10V
2	F 100Hz ± 10V
3	F 500Hz ± 10V

CONTROL OUTPUTS

62 - S1OUT

63 - S2OUT

64 - S3OUT

Setting Range: 0 ... 10

- Basic Setting = 1
- S1OUT = 1
- S2OUT = 7
- S3OUT = 6




Programming Possibilities:

S1OUT S2OUT S3OUT	MEANING	EXPLANATION
0	—	Output deactivated
1 (S1OUT)*	Failure Summary	Deactivated if Inverter is in 'Failure Stop'
2	Motor output activated	Activated if Motor is excited
3	LH Rotat. Direction	Activated if STL and Nom. Value or Stop Value are entered
4	RH Rotat. Direction	Activated if STR and Nom. Value or Stop Value are entered
5	Motor Stop	Activated if Rotational Field's frequ. is 0Hz (Stop Torque)
6 (S3OUT)*	Nominal Frequency Value reached	Activated if Operational RPM is reached (F = FS ± 0,5Hz)
7 (S2OUT)*	Frequency Boundary Value	Activated if the Rotational Field's Frequ. has exceeded the Fixed Frequ. programmed in (F > FF5)
8	Current Boundary reached	Activated if actual current boundary value is exceeded IW > ILIM
9	Brake Chopper activated	Activated if brake chopper on
10	Failure Stop	Activated if Frequ. Conv. is OFF due to Failure

* Basic Setting


Explanation:

- **S1OUT**
Special output S1OUT is a HIGH-activated output (20V DC). It furnishes a current of 80mA if activated (short circuit-proof).
- **S2/3OUT**
Special outputs S2/3OUT are LOW-activated outputs (< 1,5 V DC) with 'Open-Collector' Circuit and 'Pull-Up' resistor 10kΩ to +22V.



7.4.8

PROGRAM NUMBER 71 - PROG




PROG	PROGRAM
0	Standard
1	Reset of Parameter Block to Basic Settings
2, 3	Internal Utilization
4 ... 9999	Programs for Special Applications

7.4.9

MODULATION FREQUENCY 74 - PWM

Programming Possibilities:




PWM	MEANING
0	7,2kHz Mod. Frequency to FMAX 270Hz
1	14,4kHz Mod. Frequency to FMAX 400Hz

7.4.10

CONVERTER DATA

- 95 - ERR1 (last failure)
- 96 - ERR2 (next to last failure)
- 97 - ERR3 (second to last fail.)
- 98 - ERR4 (third to last failure)



This data contains Inverter information possibly useful for remote monitoring or for repairs. It includes a failure memory capable of storing up to 4 failure occurrences. Each entry contains the failure code (Octal code) and duration to register the failure in 1/10 of an hour.

7.5

FU2000-RT FREQUENCY INVERTER

The development of frequency inverters is now at the stage of fine tuning to suit the specific motor and its application.

Further development on the microprocessor card for the FU2000 LUMIDRIVE Frequency Inverter has fine tuned it for pulse and positioning applications. To operate pulse and positioning drives dynamically and precisely positioned with real time response and defined reaction times, a frequency inverter must have the following characteristics:

7.5.1

REAL TIME SIGNAL PROCESSING

Real time signal processing makes possible a constant reaction time to the external control commands: start clockwise, start anti-clockwise, brake, reverse and fixed frequency default (FF2).

Constant reaction time is equivalent to a maximum positive time error of 100 µs. The real time software structure implemented in the FU2000-RT increases positional accuracy compared with standard frequency inverters by a factor of between 10 and 100.

7.5.2

PARAMETRIC FILTER TIME CONSTANTS 67 - FST

Range:

- FST min = 0
- FST max = 4
- Basic setting = 4

FST	FILTER
0	off
1	2,9ms
2	8,7ms
3	20,3ms
4	43,5ms

Explanation:

Using this function the filter time constant can be pre-selected for the analogue frequency setpoint default in five stages. When using position regulators or positioning modules it is possible to optimise the reaction time of the inverter and therefore the control dynamics of the complete drive design.

7.5.4**AUTOMATIC MOMENT INCREASE DURING ACCELERATION**

- 47 - KFN1
- 51 - KNF2
- 48 - MKFN1
- 53 - MKFN2

Range:

- KFN1(2) min = 0%
- KFN1(2) max = 25%
- Basic Setting = 0%

- MKFN1(2) = 0%
- MKFN1(2) = 6%
- Basic Setting = 0%

7.5.3**SELF-OPTIMISING DYNAMIC CHOPPING PROTECTION**

The TRIP parameter (overload protection - see Section 7.4.6.) has been extended as follows:

TRIP	MEANING
0	No cutout
1	Cutout at overload current after approx 10 seconds
2	Cutout at overload current after approx 30 seconds
3	Cutout at overload current after approx 100 seconds
4	No cutout and acceleration stop
5	Cutout on overload after approx 10 seconds and acceleration stop
6	Cutout on overload after approx 30 seconds and acceleration stop
7	Cutout on overload after approx 100 seconds and acceleration stop

Explanation:

Dynamic trip protection is active during the acceleration phase. It is designed for extremely dynamic reaction and works effectively even with acceleration times of 50 - 100ms.

This function is especially suitable for pulse and positioning drives. It carries out an automatic self-optimisation of the acceleration ramp according to the load and the sluggishness of the drive system.

MKFN1(2)	MEANING
0	off
1	add on acceleration
2	subtract on hesitation
3	1 + 2
4	add on clockwise operation
5	subtract on anti-clockwise operation
6	4 + 5

Explanation:

- The value programmed in KFN1(2) is added to or subtracted from the complete U/f characteristic depending on parameter MKFN1(2).
- The set value as a percentage always relates to the supply input voltage.
- When these parameters are activated there is an automatic torque increase (voltage increase). After completion of acceleration or hesitation the increase is reduced again.

7.5.5

**AUTOMATIC VOLTAGE
INCREASE FOR SLIDING
RING MOTORS**
46 - KVB1
49 - KVB2

Range:

- KVB1(2) min = 0%
- KVB1(2) max = 25%
- Basic setting = 0%

Explanation:

- This function activates a short duration voltage increase. The increase is cancelled out after 1 second or at 3 phase frequency >5Hz.
- The set percentage always relates to the power supply input voltage.

7.5.7

**CHARACTERISTICS
CHANGEOVER**

The set of characteristics has been extended and it is now possible to switch between travel and lifting mode easily.

KSEL	Characteristics set 1 active when	Characteristics set 2 active when
0	no switchover (characteris. set 1 active)	no switchover (characteris. set 2 active)
1	$F \leq FF6$	$F > FF6$
2	$S2IND = LOW$	$S2IND = HIGH$
3	rotating field clockwise	rotating field anti-clockwise

7.5.6

MODULATION FREQUENCY
74 - PWM

PWM	MEANING
0	3,9kHz
1	5,2kHz
2	7,8kHz
3	15,6kHz

**Caution:**

- PWM3 must not be operated without the LA2000 fan running.
- Exception:
In the FU2233-RT inverter the modulation frequency of 15,6kHz is permissible even without the LA2000 running.

FU2000:

Characteristics 1	Characteristics 2
RACC1	RACC2
RDEC1	RDEC2
VB1	VB2
FN1	FN2

FU2000-RT:

Characteristics 1	Characteristics 2
RACC1	RACC2
RDEC1	RDEC2
VB1	VB2
FN1	FN2
FMIN1	FMIN2
FMAX1	FMAX2
1FF2	2FF2
KVB1	KVB2
KFN1	KFN2
MKFN1	MKFN2

Level	No.1	No.2	Abbr.	Dim.	Parameter Name	Page	Setting Range	Factory Setting	Customer Setting
	01	01	MODE	—	Operation Mode	28	1 ... 6	1	
	04	FSSEL	—		Selector for Nominal Frequency Value	32	0 ... 23	0	
Modes (Display only)									
	12	F	Hz		Output Frequency	32	0 ... 400		
	13	V	%		Output Voltage	32	0 ... 100, from U _{line}		
	18	TIME	h		Switch-ON after Reset	32	0 ... 960	4	
	19	TOP	h		Operation Hours	32	0 ... 65000	4	
Frequencies									
	21	21	FMIN1	Hz	Minimum Frequency	28	0 ... 400	0	
	22	22	FMAX1	Hz	Maximum Frequency	28	4 ... 400	50	
	23	23	1FF2	Hz	Fixed Frequency	29	0 ... 400	5	
	24	24	FF3	Hz	Fixed Frequency	29	0 ... 400	0	
	25	25	FF4	Hz	Fixed Frequency	29	0 ... 400	60	
	26	26	FF5	Hz	Reference Frequency for S2OUT	29	0 ... 400	3	
	27	27	FF6	Hz	Control Frequency Selector for U/f Curve Set	33	0 ... 400	0	
	28	FF7	Hz		Fixed Frequency (Program, via Option, Function)		0 ... 400		
Ramps									
	31	KSEL	—		U/f Curve Set Selector	33	0 ... 3	0	
	32	32	RACC1	Hz/sec	Acceleration Ramp 1*	29	0,1 ... 999	20	
	33	33	RDEC1	Hz/sec	Deceleration Ramp 1*	29	0,1 ... 999	20	
	34	34	RACC2	Hz/sec	Acceleration Ramp 2*	33	0,1 ... 999	80	
	35	35	RDEC2	Hz/sec	Deceleration Ramp 2*	33	0,1 ... 999	80	
	36	36	RSTOP	Hz/sec	STOP Deceleration Ramp	30	0 ... 999	0 = OFF	
	38	THTDC	sec		OFF Delay of DC Stop Torque	34	0 ... 5	0 = OFF	
	39	VHTDC	%		DC Stop Voltage	34	1,0 ... 15	3	
U/f Curve									
	41	41	V/F C	—	U/f Curve Selector	30	0 ... 5	0	
	42	42	VB1	%	Start Torque 1 (Boost 1)*	30	0 ... 25, from U _{line}	5	
	43	43	FN1	Hz	Nominal Frequency Point 1*	31	26 ... 960	50	
	44	VB2	%		Start Torque 2 (Boost 2)*	33	0 ... 25, from U _{line}	5	
	45	FN2	Hz		Nominal Frequency Point 2*	33	26 ... 960	50	
	46	KVB1	%		Δ Boost to 5Hz	38	0 ... 25	0	
	47	KFN1	%		Δ Boost U/f characteristics	37	0 ... 25	0	
	48	MKFN1			Mode for KFN1	37	0 ... 6	0	
	49	KVB2	%		Δ Boost to 5Hz	38	0 ... 25	0	
	51	KFN2	%		Δ Boost U/f characteristics	37	0 ... 25	0	
	53	MKFN2			Mode for KFN2	37	0 ... 6	0	
Current Boundary Value									
	56	TRIP	%		Overload Protection	34	0 ... 7	0	
	57	2FF2	Hz		Fixed Frequency 2*		0 ... 400	0	
Control Circuit									
	61	SOUTA	—		Programming of Analogous Output	35	0 ... 3	1	
	62	S1OUT	—		Programming of Control Output 1	35	0 ... 10	1	
	63	S2OUT	—		Programming of Control Output 2	35	0 ... 10	7	
	64	S3OUT	—		Programming of Control Output 3	35	0 ... 10	6	
	67	FST	—		Filter time constants	36	0 ... 4	0	
Program									
	71	PROG	—		Program No.	36	0 ... 9999	0	
	72	72	START	—	Start Option	31	0 ... 7	0	
	74	PWM	—		Modulation Frequency	36	0 ... 3	2	
Inverter Data									
	95	ERR 1	—		Last Failure	36	F00 ... 99		
	96	ERR 2	—		Next to last Failure	36	F00 ... 99		
	97	ERR 3	—		Second to last Failure	36	F00 ... 99		
	98	ERR 4	—		Third to last Failure	36	F00 ... 99		

* These parameters can be reserved in correlation to the U/f Curve Set Selector (Parameter No. 31).

CIRCUIT EXAMPLE FOR OPTIMUM TIME POSITIONING USING FU2000-RT

The following change from the factory setting can be made for pulse and positioning drives with acceleration times shorter than 0,5 seconds.


VB1 = 14% , FSSEL = 1
THTDC = 2sec
VHTDC = 15%
V/F C = 1

The maximum rotating field frequency and maximum speed is entered using parameter FMAX.


The acceleration ramp is entered using parameter RACC = ...Hz/sec.

The delay ramp (braking) is entered using parameter RSTOP = ...Hz/sec.

Signal diagram for connection example:



Connection example:




GENERAL INFO FOR THE OPERATION OF FREQUENCY INVERTERS

REMARKS CONCERNING RPM CONTROL OF AC MOTORS VIA FREQUENCY INVERTERS


AC machines are available as synchronous or as asynchronous motors. The stator coils are dimensioned in such fashion that when operated with power supply from an AC network a rotational field is generated in the motor, which pulls the rotor along. Rotational speed (RPM) is determined by the following formula:

$$n_s = \frac{f_1 \cdot 60}{p}$$

n_s = Synchronous RPM
 p = Number of pole pairs
 f_1 = Stator Frequency



Φ_1 = Flow in Stator
 I_2 = Rotor Current
 U_1 = Stator Voltage
 f_1 = Stator Frequency
 M_A = Starting Torque
 M_S = Pull-Up Torque
 M_K = Breakdown Torque
 M_N = Nominal Torque
 n_N = Nominal RPM



With known number of pole pairs and constant network frequency the motor's RPM are thus established. A stepless control carrying little loss is possible through frequency alteration with simultaneous alteration of voltage. Asynchronous motors, operated at constant network voltage and network frequency show the following ratio Torque/RPM behaviour (ref. to graph on the left). The following formula applies for Torque calculation:

$$M \sim \Phi_1 \cdot I_2 \quad \Phi_1 \sim \frac{U_1}{f_1}$$

In order to maintain constant motor torque M when altering RPM it is necessary that the magnetic flow Φ_1 remains constant. Voltage U_1 must thus be altered proportionally to frequency f_1 . Under these conditions, a frequency-controlled alteration of RPM via Frequency Inverter causes a parallel shifting of the M/n curve on the RPM axis (ref. to graph on the left).

If the stator frequency is boosted further after reaching nominal frequency and nominal voltage (with constant voltage), a field weakening occurs and thus a decrease of torque with increasing RPM.

Asynchronous motors show slight losses of RPM depending upon load, due to slippage.

n_b = Operational RPM
 p = Number of pole pairs
 f_1 = Stator Frequency
 s = Slippage

Operational RPM n_b is:

$$n_b = \frac{f_1 \cdot 60}{p} \cdot (1 - s)$$




NOTE:

This loss of RPM can be compensated through utilization of tacho-control or slippage compensation.

8.2

STANDARD GRAPHS FOR MOTOR LOADS



Graph 1

Output performance of a DS motor with FU2000 Frequency Inverter.

Graph 3

Permissible Torque curve of a DS motor with adequate ambient venting.

With large-size DS motors load must be reduced, as the motor heat cannot be dissipated sufficiently.

Graph 2

Permissible Torque curve of a self-venting DS motor.

Graph 4

Maximum permissible torque for 120sec. according to DIN 57530.


The Frequency Inverter must be chosen for increased motor current.



ATTENTION:

This curve is of general validity only. Exact info concerning thermal loads must be requested from the motor manufacturer.

BLOCK DIAGRAM



ELECTRICAL DIMENSIONING OF MOTOR DRIVES

OPERATION WITH INSTANTANEOUS START

If extremely short acceleration times are required, or an increased break-off torque, the Frequency Inverter must be dimensioned according to start-up current, instead of nominal motor current.


OPERATION OF PUMPS AND VENTING DRIVES

If pump drives or venting drives with square torque progression are to be controlled and/or regulated via Frequency Inverter, a square U/f Curve can be selected for motor noise suppression and for energy saving purpose.

MULTI-MOTOR OPERATION WITH ONE FREQUENCY INVERTER

Several motors can be controlled simultaneously by one Frequency Inverter Model PM(B)L-230/400. For dimensioning it is of importance whether the motors are to be started simultaneously or successively.

- For simultaneous start the total of all motor nominal currents must not exceed the rated current of the Frequency Inverter.
- For successive start the Frequency Inverter must be dimensioned in such fashion that the additional start-up current of the motors is taken into account.



This means:
The total of all motor nominal currents, plus the total of current peaks at start-up of all motors (appr. $6-8 \times I_N$), must not exceed the Frequency Inverter's rated current.

Reason: Each motor is added to the Frequency Inverter's output already accelerated to operational condition, which, in respect to current, is equal to subjecting the motor directly to network power supply.
Further information can be obtained from



LUST Electronic-Systeme GmbH
Gewerbestraße 5-9
D-6335 Lahnau 1

Phone 0 64 41 / 6 02-0
Telefax 0 64 41 / 6 02-37

or an authorized foreign agency.

INITIAL START-UP

INITIAL INSTALLATION

Mechanical Installation

Double-Check:

- Venting, Mounting Orientation, Minimum Distance, Ambient Conditions

Electrical Installation:

- Cable Routing and Wiring
- Protective Leads
- Disconnected motor wiring

Switch Main Power Supply 'ON'

- LED 'STOP' (yellow) glows;
- LCD Display shows 'STOP';



If a failure is displayed, examine and remove reason.

NOTE:

 Control function STL or STR is validated only if it has been activated AFTER completed self-test (Switching of pre-load relay).

Entry of Operational Data

Make entries via digital control unit (DBE).

Options

- All options not required for the particular operation must be deactivated, otherwise unwanted reactions of the drive may occur.

External Entry of Nominal Value (if equipped accordingly)

- Set jumper on pin strip X11 as required.

If possible, check rotational Direction of Drive

- Connect Rotary-Field Measuring Instrument to output terminals U, V, W, activate control function STR or STL, enter nominal value and examine rotational direction of drive.

Start-up of Drive without Motor

- Start Inverter and inspect frequency display for correct acceleration, maximum frequency, deceleration, and minimum frequency.
- After Start of system the LED 'RUN' must glow.
- If integrated potentiometer for nominal value is provided, inspect if scale settings of minimum and maximum frequency correspond to minimum and maximum frequency of the Inverter.

Switch-OFF Main Power Supply



Wait
2 minutes

ATTENTION:

Wait 2 minutes before proceeding with any activity (Time to fully discharge the capacitors) and check for absence of DC voltage on intermediate circuit terminals X1/- and X1/+, using a voltmeter set on DC.

Connect Motor Wiring

- Wire motor to X1/U, V, W, PE

Switch Main Power Supply 'ON'

- Self-test is completed after 2 to 3 seconds (Pre-load relay must activate after appr. 1 second)
- LED 'STOP' on DBE Unit glows.
- DBE Displays the following message:



If a failure appears on display, examine and remove reason.

**NOTE:**

Control functions STL or STR are validated only if they have been activated AFTER completed self-test (Switching of pre-load relay).

9.2**REPAIRS**

Each Frequency Inverter is subjected to rigorous quality testing prior to shipment, consisting of functional testing and endurance test over several hours.

This assures delivery of top-quality equipment.

No malfunctions are to be expected if all operational instructions are properly followed, and if dimensioning of the equipment is correct. Should problems arise in spite of all precautions, please return the Frequency Inverter to



LUST Electronic-Systeme GmbH
Gewerbestraße 5-9
D-6335 Lahnau 1

Phone 0 64 41 / 6 02-0
Telefax 0 64 41 / 6 02-37


or to an authorized foreign agency, accompanied by info in respect to

- 1** Description of Application
- 2** Failure message and description of malfunction
- 3** Copy of Parameter entries
- 4** Wiring Diagram


yellow green flashing



DBE DISPLAY	CONDITION / REASON	REMEDY
After Power "ON"		
	Power-OFF	<ul style="list-style-type: none"> • Check Power Supply • Check Fuses
TEST	Self-test, Pre-load on Int.Circuit	
STOP	Frequ. Inverter ready Output Stages not activated	
Green LED begins to flash after Self-Test and Switch-OFF		
Err 01	Malfunction in Computer Module	Exchange Microprocessor Module
Err 03	Short Circuit/Ground Short on Motor Output	Check Motor Wiring
Err 04	Short Circuit in Int.Circuit	Output Stage, or Brake Chopper Defective. Return Inverter to Supplier
Err 06	Parameter Block invalid	False Microprocessor Module; Exchange Print
Yellow LED flashes during Operation (Switch-OFF)		
Err 11	I • t Switch-OFF	Long-time Overload; Check Drive and Rating
Err 12	Overcurrent Switch-OFF	Overload >150%; Check Drive
Err 13	Over-/Undervoltage exceeding 10 seconds	Check Power Supply Voltage; use external Brake Chopper if large Fly-wheel Mass is to be driven.
Err 14	Temperature > 80°C	Utilize external Venting Provide Venting Attachment



Reset to Factory Settings



Read-Only Protection

